

















Aero Still



Extract fan for low-noise applications





- Motion sensor

Lineup	Motion sensor	Pull cord	Humidity sensor	Timer	Number of speeds
 Aero Still 100	✗	✗	✗	✗	1
 Aero Still 100 S	✗	✓	✗	✗	1
 Aero Still 100 T	✗	✗	✗	Turn off timer	1
 Aero Still 100 ST	✗	✓	✗	Turn off timer	1
 Aero Still 100 H	✗	✗	✓	✗	1
 Aero Still 100 SH	✗	✓	✓	Turn off timer	1
 Aero Still 100 IR	✓	✗	✗	Turn off timer	1

 Aero Still 125	×	×	×	×	1
 Aero Still 125 S	×	✓	×	×	1
 Aero Still 125 T	×	×	×	Turn off timer	1
 Aero Still 125 ST	×	✓	×	Turn off timer	1
 Aero Still 125 H	×	×	✓	Turn off timer	1
 Aero Still 125 SH	×	✓	✓	Turn off timer	1
 Aero Still 125 IR	✓	×	×	Turn off timer	1
 Aero Still 150	×	×	×	×	1
 Aero Still 150 S	×	✓	×	×	1
 Aero Still 150 T	×	×	×	Turn off timer	1
 Aero Still 150 ST	×	✓	×	Turn off timer	1
 Aero Still 150 H	×	×	✓	Turn off timer	1
 Aero Still 150 SH	×	✓	✓	Turn off timer	1

 Aero Still 150 IR	✓	✗	✗	Turn off timer	1
 Aero Still Chrome 100	✗	✗	✗	✗	1
 Aero Still Chrome 100 S	✗	✓	✗	✗	1
 Aero Still Chrome 100 T	✗	✗	✗	Turn off timer	1
 Aero Still Chrome 100 ST	✗	✓	✗	Turn off timer	1
 Aero Still Chrome 100 H	✗	✗	✓	Turn off timer	1
 Aero Still Chrome 100 SH	✗	✓	✓	Turn off timer	1
 Aero Still Chrome 100 IR	✓	✗	✗	Turn off timer	1
 Aero Still Chrome 125	✗	✗	✗	✗	1
 Aero Still Chrome 125 S	✗	✓	✗	✗	1
 Aero Still Chrome 125 T	✗	✗	✗	Turn off timer	1
 Aero Still Chrome 125 ST	✗	✓	✗	Turn off timer	1
 Aero Still Chrome 125 H	✗	✗	✓	Turn off timer	1

 Aero Still Chrome 125 SH	✗	✓	✓	Turn off timer	1
 Aero Still Chrome 125 IR	✓	✗	✗	Turn off timer	1
 Aero Still Chrome 150	✗	✗	✗	✗	1
 Aero Still Chrome 150 S	✗	✓	✗	✗	1
 Aero Still Chrome 150 T	✗	✗	✗	Turn off timer	1
 Aero Still Chrome 150 ST	✗	✓	✗	Turn off timer	1
 Aero Still Chrome 150 H	✗	✗	✓	Turn off timer	1
 Aero Still Chrome 150 SH	✗	✓	✓	Turn off timer	1
 Aero Still Chrome 150 IR	✓	✗	✗	Turn off timer	1
 Aero Still Vintage 100 S	✗	✓	✗	✗	1
 Aero Still Vintage 100	✗	✗	✗	✗	1
 Aero Still Vintage 100 T	✗	✗	✗	Turn off timer	1
 Aero Still Vintage 100 ST	✗	✓	✗	Turn off timer	1

 Aero Still Vintage 100 H	✗	✗	✓	Turn off timer	1
 Aero Still Vintage 100 SH	✗	✓	✓	Turn off timer	1
 Aero Still Vintage 100 IR	✓	✗	✗	Turn off timer	1
 Aero Still Vintage 125	✗	✗	✗	✗	1
 Aero Still Vintage 125 S	✗	✓	✗	✗	1
 Aero Still Vintage 125 T	✗	✗	✗	Turn off timer	1
 Aero Still Vintage 125 ST	✗	✓	✗	Turn off timer	1
 Aero Still Vintage 125 H	✗	✗	✓	Turn off timer	1
 Aero Still Vintage 125 SH	✗	✓	✓	Turn off timer	1
 Aero Still Vintage 125 IR	✓	✗	✗	Turn off timer	1
 Aero Still Vintage 150	✗	✗	✗	✗	1
 Aero Still Vintage 150 S	✗	✓	✗	✗	1
 Aero Still Vintage 150 T	✗	✗	✗	Turn off timer	1

 Aero Still Vintage 150 ST	✗	✓	✗	Turn off timer	1
 Aero Still Vintage 150 H	✗	✗	✓	Turn off timer	1
 Aero Still Vintage 150 SH	✗	✓	✓	Turn off timer	1
 Aero Still Vintage 150 IR	✓	✗	✗	Turn off timer	1